



Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

### **Kickstand Installation Instructions 2007-2008 Honda CRF150R / RW (big Wheel)**

#### **To install your new kickstand:**

1. Remove the sub-frame to main-frame bolt.
2. Install the kickstand on the bike at the sub-frame using the provided M8X 30mm flat head bolt. Install lower mount through the existing sidestand support using the provided M8 X 35mm hex head bolt and flat washer, if the bolt is too long cut it off with a hacksaw or die grinder. We recommend using a removable thread locking agent on the bolts.
3. Make sure that you tighten all bolts to the correct torque.
4. Periodically check the pivot bolt for tightness.

#### **Maintenance:**

Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

**NOTE:** We do not recommended starting the bike with the kickstand down, as this may cause damage to the kickstand.

#### **Manufactured and Distributed by:**

Pro Moto Billet  
11461 Lone Star Rd..  
Nampa, ID 83651  
208-466-4762