



Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

2008 KLX450R Kickstand Installation Instructions

NOTE: We recommend using a removable thread-locking agent on the bolts

To install your new kickstand:

1. Remove the stock kickstand.
2. Remove the left footpeg and footpeg bracket.
3. Locate the new left footpeg bracket that comes with your new Kick-It kickstand.
4. Install the kickstand under the new left footpeg bracket using the stock bolt on the bottom and the new supplied M12x30 hex head bolt on the top.
5. Make sure that you tighten the foot peg bracket bolts to the correct torque as specified in your owner's manual.
6. Re-install the foot peg.
7. Periodically check the foot peg mounting bolts, and kickstand pivot bolt for tightness.

Maintenance:

Clean and lubricate the kickstand pivot area after each ride. We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

CAUTION: We do not recommend starting the bike with the kickstand down, as this may cause damage to the kickstand.

Manufactured and Distributed by:

Pro Moto Billet
11461 Lone Star Rd.
Nampa, ID 83651
208-466-4762