

Why pack it when you can...

RACKIT™

BILLET ALUMINUM CARGO RACKS

BY Pro Moto Billet™



Also Available from PMB

Tool pouch/fanny pack.

Chainsaw Mounting Plate

Cargo straps

Sharkfins(Disc Guards)

View it at

www.promotobillet.com

Manufactured by:

Pro Moto Billet

11461 Lone Star Rd.

Nampa, ID 83651

208-466-4PMB

Thank you for purchasing the best looking rack in the motorcycle industry. Your new rack is constructed of 6061 billet aluminum and then anodized to give you a high quality and good-looking rack for years of backpack free riding enjoyment.

Assembly instructions for Honda XR600

NOTE: We recommend using a thread locking compound on all bolts.

1. Remove the stock toolbag from the rear fender.
2. Remove the bolts securing the rear fender to the frame side rails (underneath the fender); leave the stock fender washers in place.
3. Place the side brackets on each side of the bike.
4. Insert the two (2) M6 X 40mm long flat head (fully threaded) bolts into the fender mounting locations, screw them in far enough to hold the fender in place and install the two (2) nuts but do not tighten them down.
5. Align the rack top with the side brackets, install and tighten the four M6 X 16mm flat head bolts securing the top and sides together.
6. Tighten the side bracket bolts and nuts.
7. Make sure that all bolts are tight; check them periodically during the season.
8. If necessary, trim any bolts that might catch on the tire.

CAUTION: As with all racks on dirt bikes, they should not have excess amounts of weight put on them. Excess weight can damage the rear subframe of the motorcycle.