



Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

## **2006-2007 Honda CRF250R Kickstand Installation Instructions**

To install your new kickstand:

1. Remove the left foot peg and bracket. It is necessary to remove the footpeg from the bracket in order to remove and install the new bolts.
2. Install the kickstand under the left foot peg bracket using the stock bolts, we recommend using a removable thread-locking agent on the bolts. Check to make sure that the weld on the frame is not interfering with the kickstand mount, if necessary file the weld and bracket to allow for proper fit.
3. Make sure that you tighten the foot peg bracket bolts to the correct torque specification.
4. Re-install the foot peg.
5. Periodically check the foot peg mounting bolts and kickstand pivot bolt for tightness.

### **Maintenance:**

Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

**NOTE:** We do not recommended starting the bike with the kickstand down, as this may cause damage to the kickstand.

### **Manufactured and Distributed by:**

Pro Moto Billet  
11461 Lone Star Rd..  
Nampa, ID 83651  
208-466-4762