



Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

## **1988-2005 KX500 Kickstand Installation Instructions**

To install your new kickstand:

1. Remove the lower chain roller and bolt, make sure you keep track of the order of the small parts for re-assembly. Remove the sub-frame to main-frame bolt.
2. Install the provided subframe bolt spacer into the subframe bolt hole.
3. Install kickstand on the bike using the provided M8X 30mm flat head bolt. Re-Install the chain roller using the provided M8 X 80mm socket head bolt, if the bolt is too long cut it off with a hacksaw or die grinder. We recommend using a removable thread locking agent on the bolts.
4. Make sure that you tighten all bolts to the correct torque.
5. Periodically check the kickstand pivot bolt for tightness.

### **Maintenance:**

Clean and lubricate the kickstand pivot area after each ride. We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

**CAUTION:** We do not recommended starting the bike with the kickstand down, as this may cause damage to the kickstand.

### **Manufactured and Distributed by:**

Pro Moto Billet  
11461 Lone Star Rd..  
Nampa, ID 83651  
208-466-4762