



Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

**Instructions: KTM 05-06 SX\*05-07 EXC/MXC/XCW/XC (PMB-01-3003)**

**To install your new kickstand:**

1. Remove the stock kickstand and all kickstand brackets, if applicable.
2. Remove the lower chain roller or slide bolt, make sure you keep track of the order of the stock nut and small parts for re-assembly. Remove the sub-frame to main-frame bolt.
3. Install the kickstand on the bike using the provided 8x30mm flat head bolt at the subframe to mainframe bolt location. We recommend using a thread-locking agent on the bolts.
4. Line up and install the provided 8x20x30 spacer and 8x70mm socket head bolt into the lower mounting bracket. Install the chain roller or slide at this time if it was removed. Make sure that there is proper clearance on the length of the bolt.
5. Tighten all bolts to the correct torque.
6. Periodically check the kickstand leg pivot bolt and all mounting bolts for tightness.

**Maintenance:** Clean and lubricate the kickstand pivot area after each ride. We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

**CAUTION:** We do not recommend starting the bike with the kickstand down, as this may cause damage to the kickstand.

**Manufactured and Distributed by:**

Pro Moto Billet  
11461 Lone Star RD  
Nampa ID 83651  
208-466-4762

**Parts List:**

1-Kickstand  
1-8x70 SH  
1-8x20x30 Spacer  
1-8x30 FH

Check out our Spark Arrestor Endcaps, Billet Cargo Racks, Shark Fins and other billet accessories at...

