



Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

Kickstand Installation Instructions

2005-2007 KTM 125-525 EXC, XCW, MXC, XC, XC-F, 2005-06 SX models.

To install your new kickstand:

1. Remove the stock kickstand and all kickstand brackets, if applicable.
2. Remove the lower chain roller or slide bolt, make sure you keep track of the order of the small parts for re-assembly. Remove the sub-frame to main-frame bolt.
3. Install the kickstand on the bike using the provided M8 X 30mm flat head bolt at the subframe to mainframe bolt location. We recommend using a thread-locking agent on the bolts.
4. Line up and install the provided 1.2" lower mounting spacer and bolt, M8 X 70mm socket head, into the lower mounting bracket. Install the chain roller or slide at this time if it was removed. Make sure that there is proper clearance on the length of the bolt.
5. Tighten all bolts to the correct torque.
6. Periodically check the kickstand leg pivot bolt and all mounting bolts for tightness.

Maintenance: Clean and lubricate the kickstand pivot area after each ride. We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

CAUTION: We do not recommended starting the bike with the kickstand down, as this may cause damage to the kickstand.

Manufactured and Distributed by:

Pro Moto Billet
11461 Lone Star Rd..
Nampa, ID 83651
208-466-4762